

Pole Conversion Guide

Legacy	Standard Replacement	High EPA Replacement
907HR	08 RHNS1	–
958HR	10 RHNS1	10 RHNE1
906HR	12 RHNS1	12 RHNE1
916HR	16 RHNS1	16 RHNE1
920HR	20 RHNS1	20 RHNE1
07 08HR	08 RHTS1	–
09 08HR	10 RHTS1	10 RHTE1
11 08HR	12 RHTS1	12 RHTE1
13 08HR	14 RHTS1	14 RHTE1
15 08HR	16 RHTS1	16 RHTE1
17 08HR	18 RHTS1	18 RHTE1
19 08HR	20 RHTS1	20 RHTE1
24 08FR	25 RFTS1	25 RHTE1
29 08FR	30 RFNS1	–
926	–	–
927	–	–
928	–	–
11 08GP	12 RFTS1	12 RFTE1
13 08GP	14 RFTS1	14 RFTE1
15 08GP	16 RFTS1	16 RFTE1
17 08GP	18 RFTS1	18 RFTE1
19 08GP	20 RFTS1	20 RFTE1
24 08GP	25 RFTS1	25 RFTE1
29 08GP	30 RFTS1	–
19 08SF	20 RFTS1	20 RFTE1
24 08SF	25 RFTS1	25 RFTE1
29 08SF	30 RFNS1	–
34 08SF	35 RFTS1	35 RFTE1